

## KENWORTH EXTENDED DAY CAB INSTALLATION INSTRUCTIONS

1. Tilt and set upper edge of unit under lip of cab and rock into place.
2. Notch inside floor to allow clearance of braces and seat belt brackets. Floor should overlap onto cab by approximately 1”.
3. Once the unit is in place, clamp flange in two places on each side – upper and lower.
4. Using pop rivets and waterproof adhesive sealant, seal fiberglass floor to cab floor.
5. Install two aluminum corner braces at upper sleeper mount bolt position.
6. Install your factory rubber exterior and interior seals (not included).

This kit basically installs in the reverse order in which the existing sleeper was removed.